

Overview

The astroid Dicom App is used to provide access to functions which are used for reading a dicom file and returning more useable standard data types, such as those from the RT Types App available on the thinknode framework. The astroid Dicom App device is not an interactive end user application. Users of the system will write scripts or use a fully interactive software program that makes calls to the functions provided by the astroid Dicom App. The core functionality includes parsing dicom RT_Plan, Structure Set, CT Image, and Dose file types.

The [Dicom Manifest Guide](#) contains a complete list of all functions and types supported by the astroid Dicom App through API calls.

User Guide

The [Dicom App User Guide](#) lists all available api function calls, as well as gives examples of usage and explanation of the affects.

Getting Started Connecting to thinknode™ api and initial setup of the astroid Dicom App.

Calc Provider Examples thinknode™ example projects and usages.

Data Types astroid Dicom App datatypes available through the thinknode™ api.

Known Limitations Known application limitations, defects, or inconsistencies.

Reference Documentation

DICOM-PS3.32011]]// DICOM Part 3: Information Object Definitions specification.**
</WRAP> <WRAP half column>
/{ {:dicom:dicom_app_conformance_state ment.pdf|Dicom App Conformance Statement** .decimal astroid Dicom Conformance Statement

From:

<http://apps.dotdecimal.com/> - **decimal App Documentation**

Permanent link:

<http://apps.dotdecimal.com/doku.php?id=dicom:dicom&rev=1436559157>

Last update: **2021/07/29 18:19**

