2025/09/10 03:05 1/1 decimal eRT Settings

# decimal eRT Settings

The following settings are present within the decimal eRT settings UI accessed within the View → Settings menu:

# **App Settings**

#### Landing Page

 Allows the user to specify whether or not to view the application landing page when decimal eRT is opened.

#### Inactivity Timeout

Specifies the time out period (in minutes) to automatically log the user out of the application.
Timeout is based on mouse/keyboard interaction within the user interface. Note: This inactivity timeout is different than the user session token received from the decimal Launcher.

#### Default DICOM Directory

 Sets the default DICOM import directory. This directory will be used each time a DICOM import is attempted.

#### UI Theme

 Set the visual theme of the application (Note: the 'blue' theme is the currently supported theme. The 'dark' theme is a deprecated theme and not routinely updated.

### Local Disk Cache

The local disk cache is where calculation results are stored on the client computer. The recommended storage size for this cache is 25GB.

Refer to Data Management Storage and Caching for more information.

## **Network Disk Cache**

### **Patient Storage**

From:

http://apps.dotdecimal.com/ - decimal App Documentation

Permanent link:

http://apps.dotdecimal.com/doku.php?id=electronrt:userguide:tutorials:app\_settings&rev=1598983390

Last update: 2021/07/29 18:24

