Plan Reports

The ElectronRT App allows PDF export of treatment plan reports. Treatment plan reports include all patient, plan, and beam data and can optionally include screen shots taken in the application.

▼ Export										
▼ Plan Reports										
Report Screen Shots Add or remove screenshots for exported reports										
Screen Shot Name:										
Take Report Screen Shot										
 Export Plan Report Export the Plan Report (including saved screen shots) Open report after export Copy PDF after export Report Content Options Patient Geometry Export Dose Reference Points Imaging Export Density Overrides Beams Export Beam List Use IEC Coordinate System Export Ordered Hardware IDs 										
Export Plan Report										



Report Customization

The ElectronRT App provides options for customizing the exported plan report including: customizing the header logo and setting the different options for details that will appear on the report.

Header Logo

By default the header logo is set to the logo of the application. The header logo can be optionally overridden by the user in the Organization Configuration block. For more information please see <link to

site config wiki>



The header will be placed as shown in figure 2. The header image is not scaled and is placed on the report at it's native size.

vitient: Anon A69 Mari Pilan 3	176									
decima	al 🖪	Delauk A	pp Logo							
decimal E	lectro	nRT								
Versien 0.0.3										
Treatment	Plan Re	port								
Patient										
Name: .decimal 1D:	Anon A8937 K26963	S HRN: Patient ID	A89376 1	Birth But Sec.	et 1983 Other	l-Jan-Bi				
Course										
Course Name: Course ID: Physician:	i 1 Referring	Tre	scription stment Site			0 Facilians				
DICOM Info										
Structure Set Patient Positie		ANDRO1 Struc	tare Set Lai	H PLAN	15					
Plan										
Plan Name: Plan Descriptio		Plan 10: 1								
Imaging										
CTOWNE: G	120									
Beams										
Hachine Hodel Coordinate Sys		anTruelleam (La Ipment	st Modified	By: Alfredo	Negran-R	vera On: 2038-86-24	13:37:21)			
Beam List										
10 01 : 6356 C0 0		one 9 MeV	356 deg		deg	Tascenter (cm) -0.35, -34.45, 7.50	Entrance (cm) -0.35, -34.45, 7.50	188 cm	Applicator 6x6	

Fig. 2: Custom Header

Recommended Size

Since the custom header image is not scaled when placed into the report, it's recommended to use a size that does not interfere with the report contents or reduce the readability of the report.

As such, the recommended image size for a custom header logo is:

- Width: 200 to 500 pixels
- Height: 40 to 75 pixels

Larger sized images may still render correctly on the report as long as they fit a standard portrait letter size, but are not recommended since they may impact readability of the report. Images larger than the PDF page may have the image cropped to fit on a single page.

Screen Shots

Users are able to take screen shots to include on their treatment plan report. Screen shots will include the entire display UI including all CT, Dose, 3D, BEV, and statistics views. Once a screen shot has been

captured it will appear on the exported treatment plan report

▼ Plan Reports										
Report Screen Add or remove	Shots screenshots for exported reports									
	Ortho+DVH	×								
	DVH+Stats	×								
Screen Shot Name: 3D										
	Take Report Screen Shot									

Fig. 3: Report Screenshots

After specifying a name for the screenshot the application will allow the user to capture the current display and save the screen shot for the plan report.

Managing Screen Shots

Once a screenshot has been captured the following actions can be performed for each screen shot:

- **Preview/View:** You can view the captured screen shot by selecting the screenshot in the list of saved captures
- **Delete:** You can remove a captured screenshot so that it is no longer exported to the treatment plan report by selecting the 'X' icon next to the screenshot name.

Report Content

By default plan reports will contain all plan information currently present in the treatment plan. Users can optionally chose to not export specific content to the treatment plan report including: dose reference points, density overrides, beams, or ordered hardware information.

Coordinate System (Equipment & IEC)

By default the treatment plan report will export beam geometry information in the equipment coordinate system. Users can optionally chose to export beam coordinates using the IEC coordinate system as specified in the Machine Configuration. This option is provided as a checkbox in the Report Content Options section.

The selected coordinate system option will be displayed on the treatment plan report as either "Equipment" or "IEC" as shown in the figure 4 below.



Fig. 4: Report Coordinate System

For more information on setting the IEC coordinate systems please see <link to site config wiki>



From: https://apps.dotdecimal.com/ - **decimal App Documentation**

Permanent link: https://apps.dotdecimal.com/doku.php?id=electronrt:userguide:tutorials:plan_reports&rev=1595265641

Last update: 2021/07/29 18:24

4/4