

Defining the Dose Grid

The calculation grid resolution/size used affects the accuracy of the dose distribution. In Astroid you have the ability to vary the grid size dependent on the structure. The calculation grid base resolution is set to the patient. By using a larger grid in areas that are not critical to the calculation you have the ability to speed up the calculation. The default grid size is 8mm set to the patient. Whatever grid size you set to the patient you may scale down by in powers of 2 in the areas of critical structures and regions of interest.

From:

<https://apps.dotdecimal.com/> - **decimal App Documentation**

Permanent link:

https://apps.dotdecimal.com/doku.php?id=planning:userguide:walkthroughs:defining_dose_grid&rev=1468251859

Last update: **2021/07/29 18:25**